

# **FIDO™ DOG WASTE STATION**

## Installation Instructions - PERMANENT WALL MOUNTING


**IMPORTANT:** ENSURE THAT ALL PERSONNEL READ THE POINTS LISTED BELOW AND THAT A COPY IS PASSED ON TO STAFF INVOLVED WITH THE INSTALLATION.


### **TOOLS REQUIRED:**

Electric/Cordless Power Drill & Safety Glasses Masonry Drill Bit Number 14 (9.32") Hammer Screwdriver

### **HARDWARE**

Screws number 12 x 2.5" Round Head Screws x4
Two Hole Washer Plates x2
'C' Type Brackets x2
No. 12 wall plugs x41





- **1.** Using two-holed washer plates as a template mark drill position holes on to the wall at the desired height. ENSURE THAT BOTH SETS OF FIXING HOLES ARE MARKED VERTICALLY BELOW EACH OTHER AND ARE THE CORRECT DISTANCE APART AS SHOWN.
- 2. Drill and plug wall ready to accept screw fixings.
- **3.** Assemble washer plates, and secure from inside the dog waste station in both top and bottom positions.



GLASCION AND FIDO 25™ ARE TRADEMARKS OF GLASDON GROUP OR ITS SUBSIDIARIES IN THE U.K. AND OTHER COUNTRIES

A planned maintenance schedule of regular inspection is recommended, replacing components as necessary.

Replacement components are available direct from Glasdon, Inc.

Glasdon, Inc. cannot be held responsible for claims arising from incorrect installation, unauthorized modifications or misuse of the product.

Issue 1 August 2011 Stock no. C000/00228 Copyright 2011

Copyright 2011 Glasdon reserves the right to alter specifications without prior notice.






# **FIDO™ DOG WASTE STATION**

## Installation Instructions - PERMANENT POST MOUNTING


**IMPORTANT:** ENSURE THAT ALL PERSONNEL READ THE POINTS LISTED BELOW AND THAT A COPY IS PASSED ON TO STAFF INVOLVED WITH THE INSTALLATION.

## **TOOLS REQUIRED:**

**Installation Instructions** Screwdriver



Hold 'C' bracket c/w extension (D) to back of container body, in line with the top pair of pre-drilled holes. Using the washer plate (B) and two hex-head screws (C) fix the bracket assembly to the container.



Note: TESPA banding is not included with the kit, but is available from Glasdon UK as a separate kit.

### **HARDWARE**

A. Container Outer c/w Lid

B. Washer Plates


C. Hex Head Slotted Screw

х4 х1

x2

D. 'C' Bracket c/w Extension E. 'C' Bracket

x1



#### 2. LOWER MOUNTING

Repeat the fixing operation with second 'C' bracket (E), attach it to the container through the lower pair of pre-drilled holes.



Glasdon and fido 25™ ARE TRADEMARKS OF GLASDON GROUP OR ITS SUBSIDIARIES IN THE U.K. AND OTHER COUNTRIES

A planned maintenance schedule of regular inspection is recommended, replacing components as necessary.

Replacement components are available direct from Glasdon, Inc.

Glasdon, Inc. cannot be held responsible for claims arising from incorrect installation, unauthorized modifications or misuse of the product.

Issue 1 August 2011 Stock no. C000/00228

Glasdon reserves the right to alter specifications without prior notice.

